

# Firestick Remote

## MY OTV Operating Instructions



When the app is launched, it will play the last selected channel or the first channel in the first category. The operating instructions below assume you are viewing a channel. Please note, on the initial launch of the app, channel viewing may be slightly delayed due to downloading the TV Guide information.

- **Navigation Key “Up”:** This will open the channel submenu. There are three options on this screen: 1) add channel to the favorites, 2) apply parental controls (the default PIN is 1111 and can be changed on the **Settings** main menu), and 3) channel settings (video, audio, and subtitles). Press the press the “Up” button to exit this menu.
- **Navigation Key “Down”:** Pressing the “Down” button while in the channel menu will allow you to select the options on the screen (add a channel to favorites, apply parental controls, or turn on/off subtitles, if available).

- **Navigation Key “Right”:** Change channel down the list.
- **Navigation Key “Left”:** Change channel up the list.
- **Select Button:** This button will open the channel main menu on the left-hand side of the screen. Pressing the “Up” or “Down” button will scroll through available channels in the current category. Once you choose the desired channel, press the Select button to begin viewing.

Long Pressing the Select button will open a submenu that will allow you to add/remove a channel to the favorites, move/change the channel order, lock/unlock parental controls on the channel, and lock/unlock parental controls for a channel category. Press the “Back” button to close this submenu.

While on the channel main menu, the “Left” and “Right” navigation keys will cycle you through the channel categories at the top of the screen (i.e., entertainment, movies, kids, sports, etc.). To exit the main channel menu, press the “Back” button.

Pressing the “Menu” button will open a submenu where you can add a channel to favorites or apply parental controls.

- **Back Button:** Access the My OTV main menu. On this screen, you can access the TV Guide and Settings. Please note, not all channels have a guide. You can also exit the app from this screen.
- **Home Key:** Exit the MY OTV app.

For additional information, visit the Knowledgebase at <https://smarthomehosting.com>.